



Note:

Jet pump 1 is connected to water diverter valve 1, which is connected to group A water distributor and D swim nozzle. Group A water distributor is connected to the A1 and A2 nozzle,

Jet pump 2 is connected to the water diverter valve 2, which is connected to the group B water distributor and the E swim nozzle. Group B water distributor is connected to the B1; B2 and B3 nozzles.

Jet Pump 3 is connected to the F swim nozzle.

The circulation pump is connected to the Group C water distributor, which is connected to the C1 nozzle, waterfall, and UV sterilizer;

G air valve is connected to the A1; A2 and C1 nozzles.

H air valve is connected to the B1; B2 and B3 nozzles.

I air valve is connected to the D and E swimming pool nozzle.

J air valve is connected to F swimming pool nozzle.

The dotted circle indicates the range of the point.

The waterfall is controlled by a water inlet switch;

The air blower is connected to all bubble nozzles and aromatherapy tanks;

The air blower and waterfall are optional, please pay attention to the configuration and order requirements.

Swim jets

**3pcs jet pump+ 1pc circulation pump**

ZR6802 Spa Front View